

Ρύθμιση* Ισχύος kW -(Κωδ)	Ένταση (A)	Διατομή Καλωδίου (mm ²)	Αύξηση θερμοκρασίας (Δt)		
			25°C	30°C	35°C
			Ροή νερού σε (L / min)		
9-(127)	16 - (16A)	5x2.5	5,20	4,30	3,70
12-(170)	17 - (20A)	5x4.0	6,90	5,70	4,90
15-(212)	22 - (25A)	5x4.0	8,60	7,20	6,10
18-(250)	26 - (32A)	5x4.0	10,0	8,50	7,0
Power* Setting kW-(Code)	Current (Amps)	Cable Cross Section (mm ²)	Efficiency (Δt)		
			25°C	30°C	35°C
			Water Flow Rate (L/min)		

Απενεργοποιείτε τη συσκευή εάν αυτή έχει τεθεί σε λειτουργία αναμονής. Πατήστε παρατεταμένα το πλήκτρο (αύξηση ) μέχρι να εμφανιστεί στην οθόνη ένας τριψήφιος αριθμός (κωδικός ισχύος). Συμβουλευτείτε τον παραπάνω πίνακα για την επιθυμητή μέγιστη ισχύ και επιλέξτε με τα πλήκτρα (αύξησης  /  μείωσης) τον αντίστοιχο κωδικό ισχύος. Περιμένετε μερικά δευτερόλεπτα μέχρι να ακουστεί ένας ήχος για να καταχωρηθεί η επιλογή σας. Η συσκευή έχει προγραμματιστεί στην επιθυμητή μέγιστη ισχύ και είναι έτοιμη προς χρήση.

Turn off the  device if it is put into standby mode. Press and hold the (increase ) key until a three-digit number (power code) appears on the screen. Consult the table  above for the  desired maximum power and select with the (increase  / decrease ) keys the corresponding power code. Wait a few seconds for a sound to be heard for your selection to be registered. The device is programmed at the desired maximum power and is ready for use.

